




Package Contents:


- (1) SP-MAGKIT – Arkon Magnet Mount Kit
- (1) AP142017MM – 1/4"-20 to 17mm Adapter
- (1) SPSH1420 – Camera Hot Shoe to 1/4"-20 Camera Bolt Pattern Adapter

Magnetic mount is compatible with devices weighing up to 6.3 ounces, including those with cases.


- 1 Attach base of adapter to camera hot shoe. Screw bottom locking disk clockwise to secure adapter.



- 2 Place tightening ring over 17mm end of ball adapter and snap the Magnet Mount Kit onto adapter. Set to desired position and tighten ring. Screw 17mm Ball Adapter onto the 1/4"-20 mounting bolt. Screw top locking disk counter clockwise to secure.



- 3 Remove paper backing of adhesive metal plate. Firmly press the adhesive side to clean, back surface of your smartphone or case. Place metal plate on the smartphone in contact with the magnet head on the mount to attach. Rotate or adjust angle as needed.



OPTIONAL: Use magnet mount kit in the opposite direction and face phone towards lens.



! Safety Precautions
 Arkon is not responsible for any damages caused to your device or yourself due to the installation or use of this product.

ARKON
 RESOURCES INC. The Mobile Mounting Specialists™

Consumer Hotline:
 USA (800) 841-0884
 INT'L (626) 254-9005
 Monday - Friday 9 am - 5 pm, PST

www.arkon.com
 Arcadia, CA 91006 USA
 Designed in USA | Made in Taiwan
 ©Copyright 2016 Arkon Resources, Inc.